

Instructions for the Hot Tub

Please do not sit or lie on the hot tub cover – it is not designed to support even a child.

To take the cover off first use the key – child lock key is a small black plastic key on a hook in the outside combination box - insert in each clip and turn 90 degrees. - undo the 3 clips which hold it in place. If there are 2 people each can take a side handle and lift the cover off. Or fold the cover in half and slide it onto the deck. Remove the floating chlorine dispenser before going in to the water and put it back into the hot tub when you have finished. This should keep the chlorine levels at their optimum level. Take the cleaning sponge out.

It is important to test the water each time before it is used . Test strips are in a tub under the kitchen sink. Dip in the water for about 2 seconds and then hold it horizontal. (Bromide is not used) After 20 seconds compare it with the colours on the test tub – the normal limits are indicated on the tub. **If the test strip does not indicate normal limits for each segment do not use the hot tub - get in touch with us.** If the chlorine is a bit low unscrew the floating dispenser before you put it back after using the hot tub.

Take care what goes into the tub as this will have a profound affect on the quality of the water. In particular spray/artificial tan may be washed off. **We recommend having a shower in your costume before using the hot tub** to remove any detergent residue. Please do not allow children to go from the grass into the hot tub without washing their feet, as this can introduce bacteria into the hot tub.

The jets, air and lights are all controlled by pushing the buttons on the control panel. Press the jets button once put them on low power – press again for high power and again for off. Pressing 'Aux' turns on/off the air pump. Both of these will turn off automatically after 15 mins. Each of the jets can be closed inside the tub – and each side of the tub can be individually changed with the twist knobs on the edge of the tub. Please do not close more than half the outlets as this damages the pipe work. Please leave the waterfall running all the time whilst in use.

Put the cover back on when you have finished using the hot tub to conserve the heat.

Do not allow children under 16 to use the hot tub unsupervised.

Leave the main switch on the decking rail **ON** – the water is circulated and cleaned all the time.

Water Level

The water level, with no-one in the hot tub, should be just above the bottom of the headrest on the reclining seat. (on the right when facing the controls) If it is below the headrest add more water using the blue hose. If the level falls below the filter inlet the hot tub will shut down and stop heating to prevent damage.

**If there are any problems please phone us on 017684 83985 or 07947654174
White Cross Bay does not maintain our hot tub**